

## WAKEBOARDING QUICK START

### SET BOAT SPEED

Action	How to perform action
1. Highlight <b>Set Speed</b> .	TAP SELECT to highlight items on the screen
2. Select the desired boat speed.	TAP UP or DOWN button

## WAYPOINT QUICK START

### MAP A COURSE

Action	How to perform action
1. Display <b>Main Menu</b>	HOLD MENU button
2. Highlight <b>MAP</b>	TAP UP or DOWN button, then SELECT button
3. Select <b>Open</b>	TAP UP or DOWN button, then SELECT button
4. Highlight <b>Live Course Mapping</b>	TAP UP or DOWN button, then SELECT button
5. <b>Follow on-screen directions.</b>	TAP MENU several times to back out of screens

**ZEROFF**  
GPS SPEED CONTROL



QUICK START GUIDE(S)

**ZEROFF**  
GPS SPEED CONTROL

## JUMP SKIING QUICK START

### Step 1: IMPORTANT NOTE

Zero Off strongly recommends that you read the complete information guide for JUMP skiing. See the section *Events, Jump on page 41*.

### Step 2: JUMP LETTER SELECTION

Action	How to perform action
1. Display <b>Main Menu</b> .	HOLD MENU button
2. Highlight <b>SET</b> .	TAP UP or DOWN button, then SELECT button
3. Select <b>Jump Letter Select</b> .	TAP UP or DOWN button, then SELECT button
5. Follow on-screen directions.	TAP MENU several times to back out of screens

### Step 3: MAP A COURSE

**IMPORTANT** When mapping a jump course live, you must TAP the SELECT button when the **boat pylon** crosses the plane of the entry and exit gates.

Action	How to perform action
1. Display <b>Main Menu</b> .	HOLD MENU button
2. Highlight <b>MAP</b> .	TAP UP or DOWN button, then SELECT button
3. Select <b>Open</b> .	TAP UP or DOWN button, then SELECT button
4. Highlight <b>Live Course Mapping</b> .	TAP UP or DOWN button, then SELECT button
5. Follow on-screen directions.	<b>Important:</b> When mapping a Jump course live, TAP the SELECT button when the <b>boat pylon</b> crosses the plane of the entry and exit gates.

### Step 4: ADJUST BOAT THROTTLE

For Jump skiing, it is recommended that after the point of engagement, you push the throttle handle to the stops. This is done to make sure the speed control has full control of the motor to apply the necessary input. On a DBW boat, the maximum power output from the engine can only be where the throttle handle is set.

**WARNING:** For 2009 Indmar engines that have Throttle Override turned "on", **YOU MUST KEEP THE THROTTLE MOVING ALL THE WAY TO THE STOPS. YOU DO NOT HAVE TO IMMEDIATELY FLOOR IT, JUST KEEP THE THROTTLE MOVING.** If you stop throttle movement at engagement and then start moving it again, the boat will "take off" at full throttle because the Throttle Override is taking control.

### Step 5: SELECT TOURNAMENT OR TIMING RECAP SCREEN

Action	How to perform action
1. Highlight <b>Page Icon</b>  .	TAP SELECT to highlight items on the screen
2. Scroll to the <b>Tournament</b> or <b>Timing Recap</b> screens.	TAP UP or DOWN button

## SLALOM SKIING QUICK START

### Step 1: MAP A COURSE

**IMPORTANT** When mapping a slalom course live, you must TAP the SELECT button when the GPS antenna crosses the plane of the entry and exit gates.

Action	How to perform action
1. Display <b>Main Menu</b> .	HOLD MENU button
2. Highlight <b>MAP</b> .	TAP UP or DOWN button, then SELECT button
3. Select <b>Open</b> .	TAP UP or DOWN button, then SELECT button
4. Highlight <b>Live Course Mapping</b> .	TAP UP or DOWN button, then SELECT button
5. <b>Follow on-screen directions</b> .	<b>Important:</b> When mapping a slalom course live, you must TAP the SELECT button when the <b>GPS antenna</b> crosses the plane of the entry and exit gates.

### Step 2: SELECT PULL TYPE

Action	How to perform action
1. Highlight <b>Pull Type</b> .	TAP SELECT to highlight items on the screen
2. Select either A1, A2, A3, B1, B2, B3, C1, C2, or C3 Pull Type	TAP UP or DOWN button

### Step 3: ADJUST BOAT THROTTLE

For Slalom skiing, it is recommended that after the throttle is engaged, you push up the throttle at least 2 inches further (or to the stops) to allow Zero Off enough compensation as needed.

### Step 4: SELECT RECREATIONAL, TOURNAMENT, OR TIMING RECAP SCREEN

Action	How to perform action
1. Highlight <b>Page Icon</b>  .	TAP SELECT to highlight items on the screen
2. Scroll to the <b>Recreational, Tournament,</b> or <b>Timing Recap</b> screens.	TAP UP or DOWN button

## TRICK SKIING QUICK START

### Step 1: SELECT PULL TYPE

Action	How to perform action
1. Highlight <b>Pull Type</b> .	TAP SELECT to highlight items on the screen
2. Select either A1, A2, A3, B1, B2, B3, C1, C2, or C3 Pull Type	TAP UP or DOWN button

### Step 2: SET BOAT SPEED

Action	How to perform action
1. Highlight <b>Set Speed</b> .	TAP SELECT to highlight items on the screen
2. Select the desired boat speed.	TAP UP or DOWN button