

Indmar Products

5400 Old Millington Rd.
Millington, TN 38053
Phone 901-353-9930
Fax 901-358-4292

SERVICE ALERT

Date: 06/12/14

Alert: SA2015-9 ECM R&R

It may be necessary under certain circumstances to remove the engine's ECM for access to other components/fasteners or to replace the ECM. Removal of the ECM is a simple process but it must be done carefully to avoid damage to the ECM and/or wiring harness.

1. Remove the engine's beauty cover to gain access to ECM.
2. Make sure the ignition key/switch is in the "OFF" position.
3. Pull the ECM plug lock away from the plug to unlock and release the plug.



Locked



Unlocked

4. Remove the plug from the ECM
5. Remove the 4 socket head cap screws that hold the ECM to the bracket and remove the ECM.

Reinstallation

1. Apply a small amount of dielectric compound to the pin cavities of the ECM plug.
2. Install the ECM plug on the ECM. It will only fit one way. Lock the plug in place by pushing the lock till it clicks in place.
3. Attach the ECM to the bracket with the 4 socket head cap screws. Start all four screws by hand then snug them evenly with a ratchet wrench and appropriate driver bit.
4. Reinstall the engine's beauty cover.