

Certification Number
QD025389




PAIRING YOUR DEVICE VIA BLUETOOTH®

(REQUIRED FOR OPERATION):

1. Ensure your streaming device has Bluetooth® enabled and that power is applied to the EXMC1. (The red LED indicates the EXMC1 is powered on and the blue LED will blink blue to indicate it is in pairing mode.)
2. Within your streaming device's Bluetooth® setup menu, select "EXILE-BT2" from the list of pairable devices. No Pin Code is required.
3. When successfully connected, the Blue LED on the EXMC1 will stop blinking and remain lit. Once a device is paired then each time the device is seen by the EXMC1 it will automatically reconnect to that device. If no devices are present the EXMC1 automatically goes into pairing mode and will present itself as discoverable for the next device present.




CONNECTION DIAGRAM



FLUSH MOUNT INSTRUCTIONS

1. Drill a 1 1/8" (30mm) diameter hole.
2. Unscrew the locking nut from the back of the device and remove one of the rubber gaskets.
3. Slide the device through the hole and reattach the rubber gasket and locking nut. Orientation can be adjusted simply by loosening the locking nut and rotating the device.





TURNING THE EXMC1 ON/OFF

1. Connect the red wire (Power +12v Constant) and black wire (Ground -12v) to power and ground securely.
2. Press and hold the Power/Aux button for 3 seconds until you see the Red LED indicator on the front of the unit light up (ON) or turn off (OFF).

REMOTE IN CONNECTION

Connect the Blue wire (Remote in) to the remote wire from a head unit or other device that controls ON/OFF for the system. When the EXMC1 is used in this method the ON/OFF button is bypassed and will not function. The unit will be turned ON/OFF via the head unit or other controller.

REMOTE OUT CONNECTION

Connect the Blue with white Stripe (Remote out) wire to an amplifier remote in to turn the amplifier ON/OFF via the EXMC1. When you press the Power/Aux button for 3 seconds the EXMC1 will turn ON or OFF and also power the amplifier ON or OFF.

Note: When using the Remote in connection the Remote out feature goes into pass through mode. If an amplifier is connected to the remote out wire it will turn ON/OFF via the Remote in connection



AUX INPUT / OUTPUT

- Connect Aux input with any media player using a standard 3.5mm stereo jack.
- Double tap the Power/Aux Button rapidly to switch between the Bluetooth® source and the AUX input source. When the EXMC1 is switched to the AUX input the yellow LED on the front of the device stays on.



EXILE AUDIO
LAKE OSWEGO, OR USA
WWW.EXILEAUDIO.COM

LIMITED WARRANTY

Exile warrants this product to be free from defects in material and workmanship under normal use for a period of one (1) year from date of original purchase when purchased from an Authorized Exile Dealer. If the product is labeled B Stock/Refurbished and purchased from an Authorized Exile Dealer, it is warranted for 90 days from date of purchase, regardless of place of installation. Should service be necessary under this warranty for any reason due to manufacturing defect or malfunction during the warranty period, Exile will replace or repair (at its discretion) the defective merchandise with equivalent merchandise at no charge. Warranty replacements on B-Stock merchandise may have cosmetic scratches and blemishes. Discontinued products may be replaced with more current equivalent products. This warranty is valid only for the original purchaser and is not extended to owners of the product subsequent to the original purchaser. Any applicable implied warranties are limited in duration to a period of the express warranty as provided herein beginning with the date of the original purchase at retail, and no warranties, whether express or implied, shall apply to this product thereafter. Some states do not allow limitations on implied warranties, therefore these exclusions may not apply to you. This warranty gives you specific legal rights; however you may have other rights that vary from state to state. This warranty is only valid within the USA, for warranties outside of the USA consult the appropriate international distributor.



The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Exile Audio is under license.



aptX® software is copyright CSR plc or its group companies. All rights reserved. The aptX® mark and the aptX® logo are trademarks of CSR plc or one of its group companies and may be registered in one or more jurisdictions